




Flex-Armor™ Pre-Cut Paperback Book Cover Instructions



Remove Flex-Armor™ book cover from liner. Lay on flat smooth surface, tacky side up.



Carefully position closed book, spine down, in center of precut spine area of book cover. Rotate front of book down on to one side of cover. Smooth with Bone Folder.



Repeat for other side, by rotating book back to spine and down onto remaining side of plastic book cover.



Open book cover. Firmly smooth down remaining plastic pre-cut tabs to inside of book cover. Repeat for all edges of book cover.